

Quick Installation Guide

Package Contents

- One 56K/V.92 FAX MODEM
- One Quick Installation Guide
- One RJ-11 cable
- One Installation CD

System Requirements

- P II with 200 MHz CPU or better
- Operating System : Windows 98SE/ME/2000/XP/Vista
- 32MB RAM
- 2MB or more hard disk space

Hardware Installation

- a. Make sure that your PC is powered off. Unplug the power cord from the wall socket. Also turn off all other peripherals you may have attached to your PC.
- b. Open your PC case and locate an available PCI on the motherboard.
- c. Slide the modem into the PCI slot. Make sure that all of its pins are touching the slot's contacts. You may have to apply a bit of pressure to slide the modem all the way in. after the modem is firmly in place, secure its fastening tab to your PC's chassis with a mounting screw. Then close your PC.
- d. Plug one end of the phone cable into the Line jack on your fax modem. The other end of the phone cable should be connected directly to the phone outlet.
- e. Power on your PC

Software Installation

For Windows Vista

- a. The operating system will install all necessary driver files when modem installed. After approximately 1 minute, a message will appear at the lower right-hand corner "Your new hardware is now installed and can be used." The hardware and software installation is completed.

For Windows 98SE/ME/2000/XP

- a. Insert the Installation CD into the CD-ROM drive and select the path: Modem Card/Motorola/Windows_SM56_6.12.05_DfV/ssetup.exe to install the driver you need. This will install all necessary files from the Installation CD.
- b. The installation will be completed after clicking Finish button.

12-086-00594 Rev:02